
SERVICE MANUAL

INTEGRATED AMPLIFIER SANSUI AU-GTIX



CAUTION

- 1. Parts identified by the Asymbol on the schematic diagram and the parts list are critical for safety. Use only replacement parts that have critical characteristics recommended by the manufacturer.
- 2. Make leakage-current or resistance measurements to determine that exposed parts are acceptably insulated from the supply circuit before returning the appliance to the customer.

SPECIFICATIONS

| THE REPORT OF THE PARTY OF THE | |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------|
| Power output | |
| | driven, from 20 to 20,000 Hz, wit |
| no more than 0.008% to | |
| 25 watts per channel | |
| Load impedance | 8 ohms |
| Total harmonic distortio | |
| | less than 0.008% at or below |
| 1.大学是实生信息中心开始基础。 | rated min. RMS power outpu |
| Intermodulation distorti | |
| (60 Hz; 7 kHz=4:1 SMP | |
| | less than 0.008% at rated |
| | power output |
| Frequency response (at | |
| Overall (from AUX, C | D, TUNER, TAPE PLAY-1, 2) |
| | 10 Hz to 180,000 Hz, +0 de |
| | —3.0 dB |
| | HONO, 20 Hz to 20 kHz) |
| Input sensitivity and im | FUZ db (- U.5 db) |
| PHONO | Acquance (at 1 km2) |
| PHONO | 2.5 my/47 komms ility; 150 mV at 1 kHz, less tha |
| 0.005% total harm | |
| CD, AUX, TUNER | |
| TAPE PLAY-1, 2 | 150 mV/47 kohras |
| Signal to noise ratio (sho | |
| PHONO | |
| CD. AUX. TUNER | |
| TAPE PLAY-1, 2 | 100 dB |
| Controls and Filter | |
| BASS | +8 dB, —8 dB at 50 Hz +8 dB, —6 dB at 10 kHz |
| TREBLE | +8 dB, -6 dB at 10 kHz - |
| LOUDNESS | +9 dB at 50 Hz |
| | +5 dB at 10 kHz |
| | (VOLUME: —30 dB position) |
| Power requirements | |
| | 120/220/240V (5 0/60 Hz) |
| / For U.S.A. & Cana | |
| | 120V (60 Hz) |
| Power consumption | 7.100 watts Kated 140 watts Maximum |
| | 430 mm (16-15/16") W |
| Distriction | |

76 mm (3") H 277 mm (10-15/16") D 5.2 kg (11.7 lbs) net 6.0 kg (13.2 lbs) packed

provements.

Due to local laws and regulations, this unit sold in some areas are not equipped with variable voltage selectors.

CAUTION


1. The symbols, UL, CSA, SA, BS, UK, EU, AS and XX (EXPORT) on the parts list and the schematic diagram mean followings respectively.

| UL | Manufactured for U.S.A market. |
|-------------|---------------------------------------------|
| | (Underwriters Laboratories approved model.) |
| CSA | Manufactured for Canadian market. |
| SA | Manufactured for South African market. |
| BS, UK | Manufactured for United Kingdom market. |
| EU | Manufactured for European market. |
| AS | Manufactured for Australian market. |
| XX (EXPORT) | Standard Version. |
| NON MARK | Common Parts. |

- Some printed circuit boards are not supplied as the assembled.
 To separate these in this service manual, the stock No's are not indicated at the ends of the board names. However, the individual parts on the circuit boards are provided by orders.
- Since some of capacitors and resistors are omitted from parts lists in this service manual, refer to the Common Parts List for capacitors & resistors, which was issued on February 1983.
- 4. Abbreviations in this service manual are as follows.


| - •Abb | reviations List | |
|--------|----------------------------|----------------------------------|
| C.R. | : Carbon Resistor | E.B.L. : Low Leak Bi-Polar |
| S.R. | : Solid Resistor | Electrolytic Capacitor |
| Ce.R. | : Cement Resistor | Ta.C. : Tantalum Capacitor |
| M.R. | : Metal Film Resistor | F.C. : Film Capacitor |
| F.R. | : Fusing Resistor | M.P. : Metalized Paper Capacitor |
| N.I.R. | : Non-Inflammable Resistor | P.C. : Polystyrene Capacitor |
| A.R. | : Array Resistor | G.C. : Gimmic Capacitor |
| C.C. | : Ceramic Capacitor | A.C. : Array Capacitor |
| C.T. | : Ceramic Capacitor, | V.R. : Variable Resistor |
| | Temperature Compensation | S.V.R. : Semi Variable Resistor |
| E.C. | : Electrolytic Capacitor | SW. : Switch |
| E.L. | : Low Leak Electrolytic | Chip R.: Chip Resistor |
| | Capacitor | Chip C.: Chip Capacitor |
| E.B. | : Bi-Polar Electrolytic | |
| | Capacitor | |

1. BLOCK DIAGRAM



2. PARTS LOCATION & PARTS LIST

2-1. F-4810 Power Amp. & Power Supply Board (Stock No. 00845501)




Parts List < F-4810>

| Parts No. | Stock No. | Description |
|------------------------------|-------------|---------------------------|
| ΔiR10 | 46227800 | 10Ω 1/2W N.I.R. |
| ∆ iR11 | 46227800 | 10 Ω 1/2W N.I.R. |
| _ | | |
| jC1 | 46696000 | 0.022μF 50V F.C. |
| Transistor | | |
| ∆ kQ9 | 03067401 | 2SC1845 |
| kQ10 | 48061801 | 2SC3244 |
| kQ11 | 48064001 | 2SA1284 |
| kQ12 | 07206401 | 2SD600K |
| kQ13 | 07206301 | 2SB631K |
| ∆ kQ14 | 03068701 | 2SC2577 |
| ∆ kQ15 | 03011801 | 2SA1102 |
| ∆ kR34 | 46228600 | 47 Ω 1/2W N.I.R. |
| ∆ kR35 | 46228600 | 47Ω 1/2W N.I.R. |
| ∆ kR39 | 46230300 | 1.2k Ω 1/2W N.I.R. |
| ∆ kR40 | 46229100 | 120 Ω 1/2W N.I.R. |
| ∆ kR41 | 46227400 | 4.7Ω 1/2W N.I.R. |
| ∆ kR42 | 46227400 | 4.7Ω 1/2W N.I.R. |
| ∆ kR43 | 46644300 | 0.22 Ω ×2 3W Ce.R. |
| ∆ kR44 | 46247700 | 4.7Ω 1W N.I.R. |
| ∆ kR45 | 46247300 | 2.2 Ω 1W N.I.R. |
| kC24 | 46697600 | 0.1μF 50V F.C. |
| kL1 | 46851900 | 0.8μH Inductor |
| | or 46851901 | $0.82\mu H$ Inductor |
| •Transistor | | |
| IQ5 | 46581701 | 2SC1845 |
| 106 | 46581601 | 2SA992 |
| •IC | | |
| IIC1 | 46207600 | TA7317P |
| • Diode | | |
| ID1 | 03117600 | 1S2473T77 |
| | or 46086000 | 1S1588TP-3 |
| ID2 | 03117600 | 1S2473T77 |
| | or 46086000 | 1S1588TP-3 |
| ID3 | 03117600 | 1S2473T77 |
| | or 46086000 | 1S1588TP-3 |
| ID4 | 03117700 | 10E-2 |
| ID5 | 03111600 | 1S2473 |
| | or 03111800 | 1S1588 |
| IC1 | 46283300 | 0.022µF 50V F.C. |
| IC4 | 08460200 | 220μF 6.3V E.B. |
| IRL1 | 46254900 | Relay, Protector |

| Parts No. | Stock No. | Description |
|--------------------------------|-------------|-------------------------------|
| Transistor | | |
| ∆ mQ1 | 48061801 | 2SC3244 |
| ∆mQ2 | 48064001 | 2SA1284 |
| Militar . | 10001001 | 20,1120 |
| • Diode | | |
| ∆ mD1 | 46194700 | RB402-LFF |
| ∆ mD2 | 46273600 | DBB10-B |
| •Zener Diode | | |
| mDZ1 | 46115400 | 05Z20-Y |
| MUZI | or 46115500 | |
| 570 | | 05Z20-Z |
| mDZ2 | 46115400 | 05Z20-Y |
| | or 46115500 | 05Z20-Z |
| mDZ3 | 46113700 | 05Z11-Z |
| | or 46113800 | 05Z12-X |
| ∆ mR3 | 46228600 | 47 Ω 1/2W N.I.R. |
| ∆mR4 | 46228600 | 47Ω 1/2W N.I.R. |
| ∆mR9 | 46228800 | 68Ω 1/2W N.I.R. |
| | | |
| ∆mR10 | 46228800 | 68Ω 1/2W N.I.R. |
| ∆ mR11 | 46624900 | 330 Ω 2W N.I.R. |
| mC1 | 46606500 | 4700μF 50V E.C. |
| mC2 | 46606500 | 4700µF 50V E.C. |
| mC10 | 08680400 | 0.01 µF 500V C.C. |
| mC11 | 08680400 | 0.01 µF 500V C.C. |
| | | |
| • Transistor | 10007101 | 000000 |
| nQ1 | 46367101 | 2SC2603 |
| | or 46367301 | 2SC2458 |
| | or 46391901 | 2SC2785 |
| nQ2 | 46367101 | 2SC2603 |
| | or 46367301 | 2SC2458 |
| | or 46391901 | 2SC2785 |
| •Diode | | |
| nD1 | 03117600 | 1S2473T77 |
| IID I | or 46086000 | 1S1588TP-3 |
| 00 | 40004000 | 0 4 004 14005 |
| oS2 | 46361000 | Push SW., MODE |
| oS3 | 46361000 | Push SW., LOUDNESS |
| oZ1 | 46438100 | 2P Terminal Board, PHONO |
| oZ2 | 46363800 | 4P Terminal Board, TUNER, DA |
| oZ3 | 46363800 | 4P Terminal Board, AUX, REC-1 |
| oZ4 | 46363900 | 6P Terminal Board, PLAY-1, |
| J2-1 | 1000000 | PLAY-2, REC-2 |

2-2. F-4811 Equalizer Amp. Board (Stock No. 00845601)




Parts List

| Parts No. | Stock No. | Description | |
|-----------|-----------|------------------|--|
| •IC | | | |
| iIC1 | 46638700 | M5220P | |
| iC3 | 46654000 | 220pF 100V F.C. | |
| iC4 | 46653200 | 100pF 100V F.C. | |
| iC6 | 46697000 | 0.056µF 50V F.C. | |
| iC7 | 46695700 | 0.016µF 50V F.C. | |
| iC9 | 46282400 | 3300pF 50V F.C. | |
| iC13 | 46703300 | 0.1μF 50V F.C. | |
| | | | |

2-3. F-4812 VOLUME Control Board

Component Side




Parts List

| Parts No. | Stock No. | Description |
|-----------|-----------|----------------------|
| jVR1 | 46555900 | 150kΩ×2 V.R., VOLUME |

2-4. F-4814 Balanced Buffer Amp. Board (Stock No. 00845901)

Component Side




Parts List

| Parts No. | Stock No. | Description | |
|-----------|-------------|-----------------------------------------|--|
| •FET | | 100000000000000000000000000000000000000 | |
| kFT1 | 07110000 | μPA68H-L | |
| | or 07110001 | μPA68H-M | |
| •IC | | | |
| kIC1 | 46288800 | M5220L | |
| kC3 | 46653200 | 100pF 100V F.C. | |
| kC4 | 46655200 | 680pF 100V F.C. | |
| kC5 | 46283300 | 0.022µF 50V F.C. | |

2-5. F-4815 Tone Control Board

Component Side




Parts List

| Parts No. | Stock No. | Description | |
|-----------|-----------|------------------|--|
| jC3 | 46697300 | 0.075µF 50V F.C. | |
| iC4 | 46936900 | 0.15µF 50V F.C. | |
| iC5 | 46695500 | 0.013µF 50V F.C. | |
| jC6 | 46283500 | 0.033µF 50V F.C. | |
| jC7 | 08452000 | 4.7µF 50V E.B. | |

| Parts No. | Stock No. | Description |
|--------------|----------------------|-----------------------------------------------------|
| jVR2 jVR3 | 48149400 48149400 | 50kΩ(C) × 2 V.R., BASS 50kΩ(C) × 2 V.R., TR EBLE |
| oS4 | 46365500 | Push SW., TONE |

2-6. F-4816 Driver Amp. Board (Stock No. 00846101)

Component Side




Parts List

| Parts No. | Stock No. | Description | |
|--------------|-------------|-------------|--|
| • Transistor | | | |
| kQ3 | 03602901 | 2SA798 | |
| kQ4 | 46392001 | 2SA1175 | |
| kQ5 | 07208701 | 2SC2705 | |
| kQ6 | 07208701 | 2SC2705 | |
| kQ7 | 46728201 | 2SA1145 | |
| | or 48112901 | 2SA949 | |
| kQ8 | 46728301 | 2SC2705 | |
| | or 48113001 | 2SC2229 | |

| Stock No. | Description |
|-------------|-------------------------------------------------------------------------------------|
| | |
| 03117600 | 1S2473T77 |
| or 46086000 | 1S1588TP-3 |
| 46229800 | 470Ω 1/2W N.I.R. |
| 46229800 | 470Ω 1/2W N.I.R. |
| 46229800 | 470Ω 1/2W N.I.R. |
| 46228700 | 56Ω 1/2W N.I.R. |
| 46228700 | 56Ω 1/2W N.I.R. |
| 46840500 | 470Ω(B) S.V.R., Bias Adj. |
| | 03117600 or 46086000 46229800 46229800 46229800 46228700 46228700 |

2-7. F-4817 SPEAKERS SW. & PHONES Jack Board






Parts List

| Parts No. | Stock No. | Description | , |
|---------------|-----------|--------------------------|---|
| ∆ kR47 | 46229400 | 220 Ω 1/2W N.I.R. | , |
| oS5 | 48156600 | Push SW., SPEAKERS | |
| oJ1 | 46579600 | Jack, PHONES | |

2-8. F-4818 POWER/PROTECTOR Indicator Board


Component Side



Parts List

| Parts No. | Stock No. | Description | |
|-----------|-----------|-------------------------|--|
| nLD1 | 46169300 | LED SEL1210S, Protector | |


2-9. F-4819 Input Indicator Board



| Parts List | | | |
|------------|-----------|------------------|--|
| Parts No. | Stock No. | Description | |
| •LED | | | |
| nLD2 | 48076100 | SEL2413E, TUNER | |
| nLD3 | 48076100 | SEL2413E, CD | |
| nLD4 | 48076100 | SEL2413E, AUX | |
| nLD5 | 48076100 | SEL2413E, TAPE-1 | |
| nLD6 | 48076100 | SEL2413E, TAPE-2 | |
| nLD7 | 48076100 | SEL2413E, PHONO | |
| | | | |

2-10. F-4820 POWER SW. Board

Component Side




| Parts | Liet |
|-------|------|
| aits | FISE |

| uits List | | | | |
|--------------------------------------------------|----------------------------------------------|-----------------------------------------------------------------------------------------------------|--|--|
| Parts No. | Stock No. | Description | | |
| pC1 | 46425800 | 0.01μF 400V C.C. | | |
| ⚠ pF1 ⚠ ⚠ ♠ pF2 | 07188500 07188800 07184800 07188500 | 1.5A 250V Fuse (XX) 3A 250V Fuse (UL,CSA) 1.25A 250V Fuse (EU,BS) 1.5A 250V Fuse (XX 120V) | | |
| ApS1 | 46360300 | Push SW., POWER (XX,UL,EU,BS) | | |
| \triangle | 48064900 | Push SW., POWER (CSA) | | |
| Δ pZ1 Δ Δ Δ | 38005700 48188000 38004500 38004300 | Power Supply Cord (XX,UL) Power Supply Cord (CSA) Power Supply Cord (EU) Power Supply Cord (BS) | | |

2-11. F-4821 SPEAKERS Terminal Board


Component Side



Parts List

| Parts No. | Stock No. | Description | | |
|-----------|-----------|-----------------------------|--|--|
| oZ6 | 48148900 | 4P Terminal Board, SPEAKERS | | |

2-12. F-4829 INPUT SELECTOR SW. Board




Parts List


| T W. ED E.D. | | | | |
|--------------|-----------|--------------------------|--|--|
| Parts No. | Stock No. | Description | | |
| o\$1 | 48149300 | Push SW., INPUT SELECTOR | | |

3. OTHER PARTS

3-1. Front View




3-2. Top View



| Parts No. | Stock No. | Description |
|-------------|-----------|--------------------------------------------|
| 1 | 47707300 | Front Panel Ass'y |
| 2 | 47708300 | Bonnet |
| 3 | 48149300 | Push SW., INPUT SELECTOR |
| 4 | 47637400 | Joint Shaft 2 |
| 5 | 47706910 | Knob, VOLUME (Left) |
| 6 | 47707000 | Knob, VOLUME (Right) |
| 7 | 46555900 | 150kΩ×2 V.R., VOLUME |
| 8 | 47636300 | Knob, LOUDNESS, MODE, TONE |
| | | SPEAKERS |
| 9 | 47149200 | Joint Shaft, LOUDNESS, MODE |
| 10 | 46361000 | Push SW., LOUDNESS, MODE |
| 11 | 46365500 | Push SW., TONE |
| 12 | 47658500 | Knob, BASS, TREBLE |
| 13 | 48149400 | $50k\Omega(C) \times 2$ V.R., BASS, TREBLE |
| 14 | 48156600 | Push SW., SPEAKERS |
| 15 | 46579600 | Jack, PHONES |
| 16 | 47633700 | Knob, POWER |
| 17 | 47637300 | Joint Shaft 1, POWER |
| ∆ 18 | 46360300 | Push SW., POWER |
| | | (XX,UL,EU,BS) |
| \triangle | 48064900 | Push SW., POWER (CSA) |

| Parts List < To | <u> </u> | Description | | |
|---------------------------|----------|--------------------------------|--|--|
| Parts No. Stock No. | | Description | | |
| 1 | 47315610 | Side Panel Ass'y (L | | |
| △ 2 | 15018901 | Power Transformer (XX) | | |
| \triangle | 15018902 | Power Transformer (UL,CSA) | | |
| ∆ 2 ∆ ∆ | 15018905 | Power Transformer (EU,BS) | | |
| 3 | 47157300 | AC Cord Cover | | |
| A 4 | 46407700 | Power Supply Cord(XX,UL,CSA) | | |
| \triangle | 38004500 | Power Supply Cord (EU) | | |
| 3 Δ 4 Δ Δ Δ 5 | 38004300 | Power Supply Cord (BS) | | |
| ▲ 5 | 48062100 | Slide SW., VOLTACE SELECTOR | | |
| | | (XX) | | |
| \triangle | 46739400 | Slide SW., VOLTACE SELECTOR | | |
| | | (EU,BS) | | |
| △ 6 | 48076600 | AC Outlet (XX,UL,CSA) | | |
| \triangle | 46161000 | AC Outlet (EU) | | |
| 7 | 48148900 | 4P Terminal, SPEAKERS | | |
| 8 | 46363900 | 6P Terminal Board, PLAY-1, | | |
| | | PLAY-2, REC-2 | | |
| 9 | 46363800 | 4P Terminal Board, R EC-1, AUX | | |
| | | CD, TUNER | | |
| 10 | 22301510 | Ground Terminal | | |
| 11 | 46438100 | 2P Terminal Board, P HONO | | |
| 12 | 47314820 | Side Panel Ass'y (R | | |



5. ADJUSTMENT (See Top View on page 9)

Note: 1) Master Volume Minimum 2) Room Temperature 18°C ~ 28°C (65°F ~ 83°F)


- 3) For this adjustment, run the unit for more than 5 minutes after the power is switched ON.
- 4) Before turning ON power switch, set kVR1 on

F-4810 to center position.


| STEP | SUBJECT | MEASURE OUTPUT | ADJUST | ADJUST FOR | REMARKS |
|------|---------------------------|--------------------------------------------------------------------------|------------------------|-------------|---------|
| 1. | Bias Current Adj. L-CH | Between emitters of power transistors (kQ14 & kQ15) (Across kR43L) | kVR1, L-ch (F-4816) | DC 15mV±3mV | |
| 2. | Bias Current Adj. R-CH | Between emitters of power transistors (kQ14 & kQ15) (Across kR43R) | kVR1, R-ch (F-4816) | DC 15mV±3mV | |

6. INTERIOR BLOCK DIAGRAM OF IC


•M5220L (OP Amp. IC)



•TA7317P (Speaker Protector IC)



•M5220P (OP Amp. IC)




7. PACKING LIST

Parts No. 07599500 07827220 47708800 Vinyl Cover Styrofoam Packing Carton Case

8. ACCESSORY LIST

| S | tock No. | Descript | tion | |
|---|----------|-----------|-----------|------|
| 4 | 6960900 | Operation | g Instruc | tion |





SANSUI ELECTRIC CO., LTD.: SANSUL ELECTRONICS CORPORATION:

14-1, Izumi 2-chome, Suginami-ku, Tokyo 168 Japan
PHONE: (03) 324-8891/TELEX: 232-2076 (International Division)
1250 Valley Brook Ave. Lyndhurst. N.J. 07071 U.S.A.
17150 South Margay Ave. Carson, California 90746 U.S.A.
3036 Koapaka Street. Honolulu, Hawaii 96819 U.S.A.
Unit 10A, Lyon Industrial Estate, Rockware Avenue, Geenford, Middx UB6. A. England
Pau Ehrich Strasse 8, 6074 Rödermark 2, West Germany

(SM1-209)

Printed in Japan (N40120M) < Stock N: 36499300>